




OS-10

Multimedia Active Speaker Manual



For Multi-language Instructions:

Please scan the QR code. You will be guided to select and view/download the manual in your preferred language.

IMPORTANT SAFETY INSTRUCTIONS

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.



 The lightning flash is intended to alert you to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute an electric shock to persons.

 The exclamation point is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Before connecting or using this apparatus, do read carefully all safety warning and instructions. Please keep this instruction for future reference.

This device should be installed or set up in a position that ventilation can be assured.

Never put the device in a place that air flow over the ventilation openings might be hindered, such as in a bookshelf or a drawer.

This product should be operated only from the type of power source indicated on the back panel of the device. The power cord of this product should be restored in a place that is less possibly be walked on or get pierced, especially its plug, convenience receptacles and the point where power cord exit from the apparatus.

Before cleaning this product, make sure the plug is disconnected from the outlet. Proceed with the cleaning in the way that this instruction recommends only.

When this product is not in use for a long time, make sure to unplug the power cord from the AC outlet.

If below problem happens, send this product to a qualified service personnel for repairing.

A. Power cord or power plug is damaged.

B. Objects have fallen or liquid has been spilled into this product.

C. This product is exposed to rain or other liquid.

D. This product functions abnormally or very poorly.

E. This product has been dropped or has a damaged enclosure.

Never to attempt to repair this product by yourself. Refer all servicing to a qualified servicing personnel.

CAUTION

To reduce the risk of electric shock, the power plug must be completely inserted into an AC outlet.

This product does not contain any parts or components that can be repaired by users themselves. Do not open the enclosure, otherwise it may result in an electric shock. Refer all servicing to a qualified servicing personnel.

When you unplug this product from AC outlet, do hold the power plug and pull.

Do not pull the power cord. Do not overload AC outlets or the extension cord, as this can lead to risk of fire or electric shock.

Warning

When repairing or replacement of parts is required, make sure the service technician has used the parts/components specified by the manufacturer or parts/components that have the same characteristics as the original parts/components. Unauthorized substitutions may result in risk of fire, electric shock or other hazards.

POWER SOURCE

Before connecting this product with AC outlet, do check and make sure the electric supply voltage is as same as it is marked on the rear panel of this product.

WARNING: It's very dangerous to insert a power plug that has bare wire into an AC outlet.

DECLARATION

This product does not contain any parts or components that can be repaired by users themselves. If there is any malfunction, refer to this instruction or ask for repair by a qualified service technician. Do not try to repair by yourself, otherwise the manufacturer will not be responsible for any consequences resulted there from.

operating temperature: 0°C-40°C

Hereby, (Zhuhai HiVi Technology Co., Ltd.) declares that the radio equipment type [Multimedia Active Speaker] is compliance with Directive 2014/53/EU.




The full text of the EU declaration of conformity is available at the following internet address: www.swanspeakers.com




Operating Frequency Range	The maximum RF Output Power
Bluetooth 2402-2480 MHZ	-0.47dBm

Unpacking & Schematic Diagram

Please make sure all the following components are in the box.




Unpacking & Schematic Diagram



- | | |
|--|------------------------------------|
| 1. Tweeter | 2. Woofer |
| 3. Receiver | |
| 4. RCA to 3.5mm Audio Cable | 5. Speaker Connection Cable |
| 6. Optical Connection Cable | |
| 7. Power | 8. Touch Panel Light On/Off Button |
| 9. AUX Input | 10. Optical Input |
| 11. Coaxial Input | 12. Bluetooth Input |
| 13. Input Mode Select | 14. Mute |
| 15. Volume Down | 16. Volume Up |
| 17. Optical Interface | 18. Coaxial Interface |
| 19. Aux Interface | 20. Power Cable |
| 21. Left Speaker Out | 22. Left Speaker In |
| 23. Power | |
| After long-pressing for standby, touch any key to wake up in standby mode. | |
| 24. Input select | |
| Press to select inputs. | |
| 25. Volume control | |
| Press to increase volume; Press to decrease volume. | |
| 26. Mute | |
| Long press for 3s (when flash in red, the product is in mute mode). | |
| Remarks: | |
| Touch panel light is on when turn on the unit, and its OFF function works only after one time operation of standby and power on. | |
| Touch panel light is off if not operations in 5 minutes. Users can touch any keys on touch panel to wake up the light. | |



Speaker Connection




-
- a) Connection of master speaker and slave speaker.
 - b) Connect master speaker to the power source.
 - c) Optical connection with CD Player/DVD Player/TV.
 - d) AUX connection with computers, TV or tablets etc.
-

Bluetooth Connection

Press mode select key  on touch panel or BT on remote control to switch to Bluetooth mode. It will flash "BT" on the touch panel if Bluetooth is in pairing status. Search to connect Bluetooth (Bluetooth name: OS-10) on your device. It will continuously display "BT" if connected.



Speaker Placement



Specifications

Series:	Multimedia Active Speaker
Model:	OS-10
System Type:	2-way 4th-order vented speaker system
Drivers Configuration:	4" woofer, 20mm soft dome tweeter
Frequency Response:	60Hz - 20kHz($\pm 3\text{dB}$, Free Space)
Audio Input:	Bluetooth 5.0/Optical/Coaxial/Line
Output Power:	31w+31w RMS, Total 62w RMS
DSP Active Filter Frequency:	2.6kHz
Dimensions (W×H×D):	133×202×190mm
Net Weight (each):	Master: 2.2kg Slave: 2.0kg

Product Off-Mode Power Consumption: $\leq 0.5\text{W}$

Standby Power Consumption: $\leq 0.5\text{W}/\leq 0.8\text{W}$ (if status display is active)

The product will automatically enter low-power standby mode after 15 minutes of inactivity.

Burn-in


Burn-in is the procedure which can enable the speakers to perform best acoustically. A period ranging from 48-100 hours of usage is recommended before both the amplifier and speaker drivers behave optimally.

Alternatively, you can listen 2 or 3 hours every day at a medium volume, and the speakers will be burned-in one month or so.


Maintenance




a)



b)



c)



d)



e)

- a) Avoid magnetic disturbance.
- b) Do not place under the sunshine for a long time.
- c) Do not place in high temperature or moist environment for a long time.
- d) Do not touch the drivers with your hands.
- e) Avoid corrosive liquids and gases.

Trouble Shooting

1. If there is problem with sound quality.

- a) Check if all the drivers are working.
- b) Check that audio cables are firmly connected at both ends.

2. If there is no sound from either of the speakers:

- a) Check if the device is on and if a source is playing.
- b) Check if the volume is not on minimum.
- c) Check if there is broken or short circuit with the cable connecting speakers and audio source.

3. If there is no sound coming from one of the speakers:

- a) Check the setting of the audio source.
- b) Check that all the audio cable are firmly connected at both ends.

After-Sales services

If you still could not resolve your issue, please contact the seller for customer service.

Notice

1. Using the same type or similar type of battery, otherwise it may cause explosion.
2. Keep the battery away from sunlight, heat or fire.
3. Please remove batteries from the remote, if it is not used for a long time.
4. If the battery is aged, the effective control distance of the remote will be less.

Change the battery when this happens.

5.  The crossed-out wheeled bin symbol on this product indicates that electrical and electronic products should not be disposed of as unsorted municipal waste. Please dispose of waste equipment at designated collection points for separate collection and recycling.
6.  This icon means this product is a CLASS II device or it comes with double insulation. It does not need earth lead.
7.  This icon means this product is only suitable for indoor use.

EU Declaration of Conformity

We, hereby declare that the essential requirements set out in the **RED Directive 2014/53/EU**, have been fully fulfilled on our product with indication as below:

Product Name Multimedia Active Speaker

Brand Name / Model  / OS-10

The following standards have been applied for the investigation of compliance:

☒ Safety	EN IEC 62368-1: 2020+A11:2020
☒ Health	EN 62479:2010 EN 50663:2017
☒ EMC	ETSI EN 301 489-1 V2.2.3 (2019-11) ETSI EN 301 489-17 V3.2.4 (2020-09)
	EN 55032: 2015/A11:2020 EN IEC 61000-3-2:2019/A1:2021 EN 61000-3-3:2013/A1:2019 EN 55035:2017/A11:2020
☒ Radio	ETSI EN 300 328 V2.2.2 (2019-07)

The conformity assessment procedure referred to in Article 17 and detailed in Annex III of Directive 2014/53/EU has been followed with the involvement of the following Notified Body:

2280 MiCOM Labs Inc.
and issued the EU-type examination certificate.
Furthermore, the ISO requirement for the in-process quality control procedure as well as the manufacturing process has been reached. The technical document as well as the test reports will be kept for a period of at least 10 years after the last product has been manufactured at the disposal of the relevant national authorities of any Member State for inspection.
Detail contact information for this declaration has been listed below as the window of any issues relevant for this declaration.

Manufacturer Information:

Company	Zhuhai HiVi Technology Co., Ltd.		
Address	NO.1, South Dongcheng Road, Liangang Industrial Zone, Zhuhai, Guangdong, P.R. China		
Name/Title	Vemi Liang/Product Certification Specialist	E-mail	vemi.liang@swanspeakers.com
Tel. No.	+86-18198795340	Fax No.	

Vemi Liang

Signature / stamp Date, Mar.10, 2025



www.swanspeakers.com <https://www.facebook.com/SwansSpeakers/> Ver3
Zhuhai HiVi Technology Co., Ltd. E-mail: global@swanspeakers.com
No.1, South Dongcheng Road, Liangang Industrial Zone, Zhuhai, Guangdong, P.R.China

Due to the reasons in the change of design or others, product information contained here may not be in conformity with product itself. We reserve the right of no prior notice before change.