




M10 Plus

Multimedia Active Speaker Manual



For Multi-language Instructions:

Please scan the QR code. You will be guided to select and view/download the manual in your preferred language.

Warning

IMPORTANT SAFETY INSTRUCTIONS

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.



 The lightning flash is intended to alert you to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute an electric shock to persons.

 The exclamation point is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Before connecting or using this apparatus, do read carefully all safety warning and instructions. Please keep this instruction for future reference.

This device should be installed or set up in a position that ventilation can be assured.

Never put the device in a place that air flow over the ventilation openings might be hindered, such as in a bookshelf or a drawer.

This product should be operated only from the type of power source indicated on the back panel of the device. The power cord of this product should be restored in a place that is less possibly be walked on or get pierced, especially its plug, convenience receptacles and the point where power cord exit from the apparatus.

Before cleaning this product, make sure the plug is disconnected from the outlet. Proceed with the cleaning in the way that this instruction recommends only.

When this product is not in use for a long time, make sure to unplug the power cord from the AC outlet.

If below problem happens, send this product to a qualified service personnel for repairing.

A. Power cord or power plug is damaged.

B. Objects have fallen or liquid has been spilled into this product.

C. This product is exposed to rain or other liquid.

D. This product functions abnormally or very poorly.

E. This product has been dropped or has a damaged enclosure.

Never to attempt to repair this product by yourself. Refer all servicing to a qualified servicing personnel.

CAUTION

To reduce the risk of electric shock, the power plug must be completely inserted into an AC outlet.

This product does not contain any parts or components that can be repaired by users themselves. Do not open the enclosure, otherwise it may result in an electric shock. Refer all servicing to a qualified servicing personnel.

When you unplug this product from AC outlet, do hold the power plug and pull.

Do not pull the power cord. Do not overload AC outlets or the extension cord, as this can lead to risk of fire or electric shock.

Warning

When repairing or replacement of parts is required, make sure the service technician has used the parts/components specified by the manufacturer or parts/components that have the same characteristics as the original parts/components. Unauthorized substitutions may result in risk of fire, electric shock or other hazards.

POWER SOURCE

Before connecting this product with AC outlet, do check and make sure the electric supply voltage is as same as it is marked on the rear panel of this product.

WARNING: It's very dangerous to insert a power plug that has bare wire into an AC outlet.

DECLARATION

This product does not contain any parts or components that can be repaired by users themselves. If there is any malfunction, refer to this instruction or ask for repair by a qualified service technician. Do not try to repair by yourself, otherwise the manufacturer will not be responsible for any consequences resulted there from.

operating temperature: 0°C-40°C

Hereby, (Zhuhai HiVi Technology Co., Ltd.) declares that the radio equipment type [Multimedia Active Speaker] is compliance with Directive 2014/53/EU.



The full text of the EU declaration of conformity is available at the following internet address: www.swanspeakers.com




Operating Frequency Range	The maximum RF Output Power
Bluetooth 2402-2480 MHZ	-0.47dBm

Unpacking & Schematic Diagram


Please make sure all the following components are in the box.



Manual



Unpacking & Schematic Diagram



1. Dome Tweeter

3. Woofer

5. Volume Control: Turn counterclockwise to reduce the volume.
Push repeatedly to switch among the available modes
(AUX, Bluetooth...)
2. Midwoofer

4. Receiver / Indicator Light
6. RCA to 3.5mm Audio Cable
7. Standby

9. AUX Input (Indicator Light Light Blue)

11. Coaxial Input (Indicator Light Purple)

13. INPUT

15. Volume Down
8. LED: ON / OFF

10. Optical Input (Indicator Light White)

12. Bluetooth Input (Indicator Light Blue)

14. Mute (Indicator Light Red)

16. Volume Up
17. Coaxial Interface

19. AUX Interface


21. Speaker Out

23. Subwoofer Volume
18. Optical Interface

20. Power Cable

22. Power Switch: ON / OFF



Speaker Connection




- a) Connection between speakers.
- b) Connect speaker to the power source.
- c) Optical connection with CD Player/DVD Player/TV.
- d) AUX connection with computers, TV or tablets etc.

Bluetooth Connection

Select Bluetooth mode via the remote control or press INPUT/VOLUME control on the front panel. Indicator light should flash blue. Choose M10 Plus on your phone. Steady blue light indicates successful Bluetooth connection.



Speaker Placement



Specifications

Model:	M10 Plus	
Series:	DSP active 2.1 speaker	
Model:	M10 Plus subwoofer	M10 Plus S Satellite Speaker
System Type:	1-way vented active subwoofer	2-way 2nd-order sealed speaker system
Drivers Configuration:	5"subwoofer	3" midwoofer, 20mm soft dome tweeter
Frequency Response:	55Hz - 140Hz	140Hz - 20kHz
Audio Input:	Bluetooth/Optical/Coaxial/Line	
Output Power:	30W RMS	15W RMSx2
DSP Active Filter Frequency:	140Hz	3.0kHz
Bass Tuning:	±6dB	
Dimensions (W×H×D):	253x177x235mm	110x177x108mm
Net Weight (each):	2.8kg	2x0.75kg

Specifications

Product Off-Mode Power Consumption: $\leq 0.5W$

Product Standby Power Consumption: $\leq 0.5W$

After 15 minutes without audio input or operation, the unit will automatically enter low-power standby mode. To wake it up, press the **POWER** button on the remote control.

Burn-in


Burn-in is the procedure which can enable the speakers to perform best acoustically. A period ranging from 48-100 hours of usage is recommended before both the amplifier and speaker drivers behave optimally.

Alternatively, you can listen 2 or 3 hours every day at a medium volume, and the speakers will be burned-in one month or so.


Maintenance




a)



b)



c)



d)



e)

- a) Avoid magnetic disturbance.
- b) Do not place under the sunshine for a long time.
- c) Do not place in high temperature or moist environment for a long time.
- d) Do not touch the drivers with your hands.
- e) Avoid corrosive liquids and gases.

Trouble Shooting

1. If there is problem with sound quality.
 - a) Check if all the drivers are working.
 - b) Check that audio cables are firmly connected at both ends.
2. If there is no sound from either of the speakers:
 - a) Check if the device is on and if a source is playing.
 - b) Check if the volume is not on minimum.
 - c) Check if there is broken or short circuit with the cable connecting speakers and audio source.
3. If there is no sound coming from one of the speakers:
 - a) Check the setting of the audio source.
 - b) Check that all the audio cable are firmly connected at both ends.

After-Sales services

If you still could not resolve your issue, please contact the seller for customer service.

Notice

1. Using the same type or similar type of battery, otherwise it may cause explosion.
2. Keep the battery away from sunlight, heat or fire.
3. Please remove batteries from the remote, if it is not used for a long time.
4. If the battery is aged, the effective control distance of the remote will be less.
Change the battery when this happens.
5.  The crossed-out wheeled bin symbol on this product indicates that electrical and electronic products should not be disposed of as unsorted municipal waste. Please dispose of waste equipment at designated collection points for separate collection and recycling.
6.  This icon means this product is a CLASS II device or it comes with double insulation. It does not need earth lead.
7.  This icon means this product is only suitable for indoor use.

EU Declaration of Conformity

We, hereby declare that the essential requirements set out in the **RED Directive 2014/53/EU**, have been fully fulfilled on our product with indication as below:

Product Name Multimedia Active Speaker

Model M10 Plus

The following standards have been applied for the investigation of compliance:

☒ Safety	EN IEC 62368-1: 2020+A11:2020
☒ Health	EN 62479:2010 EN 50663:2017
☒ EMC	ETSI EN 301 489-1 V2.2.3 (2019-11) ETSI EN 301 489-17 V3.2.4 (2020-09)
	EN 55032: 2015/A11:2020 EN IEC 61000-3-2:2019/A1:2021 EN 61000-3-3:2013/A1:2019 EN 55035:2017/A11:2020
☒ Radio	ETSI EN 300 328 V2.2.2 (2019-07)

The conformity assessment procedure referred to in Article 17 and detailed in Annex III of Directive 2014/53/EU has been followed with the involvement of the following Notified Body:

2280 MiCOM Labs Inc.

and issued the EU-type examination certificate.

Furthermore, the ISO requirement for the in-process quality control procedure as well as the manufacturing process has been reached. The technical document as well as the test reports will be kept for a period at least 10 years after the last product has been manufactured at the disposal of the relevant national authorities of any Member State for inspection.

Detail contact information for this declaration has been listed below as the window of any issues relevant for this declaration.

Manufacturer Information:

Company Zhuhai HiVi Technology Co., Ltd.

Address NO.1, South Dongcheng Road, Liangang Industrial Zone, Zhuhai, Guangdong, P.R. China

Name/Title Vemi Liang/Product Certification Specialist E-mail vemi.liang@swanspeakers.com

Tel. No. +86-18198795340 Fax No.

Signature / stamp  Date: Mar 10, 2025

