



SWAN E1
User Manual

Thank you for choosing our wireless speakers.

Please read this manual carefully and keep it for future reference.



If you need any help, please contact us with your order number and details of the problem.

Package Content

1. SWAN E1 Speaker *1
2. Storage cloth bag *1
3. User Manual *1
4. USB-A to USB-C charging cable

SPEC

Model	SWAN E1
BT Version	5.3
BT Profile	A2DP, AVRCP
Power	MID-bass driver,16w+Tweeter,8w
THD+N	<0.3%
Frequency Response	60Hz~16kHz
S/N	80db
Battery	Built-in Rechargeable Li-ion Battery 18650 / 2500mAh*2 / 7.4V
Type C	DC5V/2.0A
Charging Time	4~6H
Play Time	10H
IP Level	IPX5



Product Overview

- ① Power on/Power off/Play/Pause
- ② Bluetooth pair/TWS pair
- ③ LED indicator
- ④ Vol-/Previous
- ⑤ Vol+/Next
- ⑥ Hang hole
- ⑦ USB-C port
- ⑧ Speaker front face

Operation

Charging

Although the speaker comes with a partial charge, be sure to fully charge it before using it for the first time.

The speaker's red LED lights on when charging and goes off when fully charged. The full charging time of the speaker is about 6 hours.

Low Battery

When the red LED indicator of the speaker flashes, its volume will automatically decrease. At this time, please charge the speaker in time.

Power on/off

Press and hold the power button for 2 seconds, and the blue LED indicator will light up. When you hear the corresponding startup tone, it means that the speaker has been started; In the startup state, long press the power button for 2 seconds, and the LED indicator is off. When you hear a shutdown tone, the speaker is powered off.

Pairing to use

1. When used for the first time, place the E1 wireless speaker within 1 meter of the device.
2. Long press the power on key 2s, at this time you will hear the "heartbeat" prompt tone, the speaker will automatically enter the pairing mode, the blue LED flashes.
3. Open the Bluetooth list of your mobile phone, find and select the "SWAN E1" speaker for connection.
4. If your device requires a PIN or password, enter "0000".

5. When the device has been successfully paired, you will hear the prompt tone, and then the blue LED light will remain on.

Note: On some devices, you may have to select Use the speaker as an Audio Device (Stereo) or a similar option on the device's audio menu.

TWS stereo pairing (need two SWAN E1)

1. Press once the Bluetooth pair "W" button on the two speakers respectively. The blue LED indicator on the two speakers blinks rapidly.

2. Press and hold the Bluetooth pair "W" button on the two speakers for 2 seconds respectively. At this time, the LED indicator of the two speakers will switch to the white rapid flashing state.

3. Wait until the white LED indicator of one speaker switches to slow breathing, indicating that the two speakers have been successfully paired for wireless stereo(TWS), at this time, you can go to the Bluetooth list of your phone to find "SWAN E1" for connection.

Note: To quit TWS mode for two SWAN E1, just press and hold the Bluetooth pair "W" button on one of the speakers.

Pair another phone to use

In order to connect the speaker to your another phone, make sure the speaker is in pairing mode.

1. Ensure that the speaker has been turned on.

2. Press the Bluetooth pair "W" button, when you see the blue LED indicator flashing, the speaker has entered the pairing mode, you can see "SWAN E1" on the Bluetooth list of the device, just select the name to connect.

3. When the device is successfully paired, you can hear the corresponding "paired successfully" tone, and the blue LED will remain steady on in playback mode.

Note:

When the last connected device enters pairing mode, the speaker will automatically connect to it.

If pairing is not completed within 3 minutes, turn off the speaker and try again. If there is no

LED Indicator

Bluetooth mode	• Pairing status: The blue LED indicator blinks quickly • Pairing successful (not playing): The blue LED light on • Pairing successful (playing): The blue LED breathing flash • TWS pairing status: The white LED indicator blinks quickly • TWS paired successfully (not playing): The white LED is on • TWS pairing successful (playing): White LED light breathing flash
Charging	• Charging: The red indicator is on • Fully charged: Red light goes off

Button Instruction

Button	Function
Power on/off button	- Long press the power button for 2 seconds to turn the speaker on/off; - Under a Bluetooth connection, you can click the power button to play/pause music.
Bluetooth pair "W" button	- Under the Bluetooth connection, you can click the wireless button to enter pairing mode of the speaker. - Press again to quickly connect back to the last connected device. - Press and hold for 2 seconds to enter TWS pairing mode. - Press and hold Bluetooth pair "W" button 2 seconds in TWS group pairing mode can make two speakers quit TWS connection. At this time, if the host is still connected to the mobile phone, long press the Bluetooth pair "W" button 2 seconds to make the two speakers recover TWS connection.
Vol+ /Next button	- Press Vol+ / Next button to increase volume. - Press and hold the Vol+ / Next button to move to the next song.
Vol-/Previous button	- Press Vol- / Previous button to decrease volume. - Press and hold the Vol- / Previous button to move to the previous song.

Manufacturer: Zhuhai Hivi Technology Co., LTD
Add: No.1 Dongcheng Road South, Liangang Industrial Zone, Zhuhai City
Implementation standard: GB8898-2011
Website: www.hivi.com
Service hotline: 400-0909-199